



411 West Congress St. , Maple Lake, MN 55358 Toll Free: 877-466-8837 www.wavearmor.net

RAFT ANCHOR

PARTS LIST:

ITEM	DESCRIPTION	QTY
1	ANCHOR	1
2	½ "EYE BOLT 6" LG	1
3	½" FLAT WASHER	2
4	½" HEX NUT	1
5	½" NYLOCK NUT	1

ASSEMBLY INSTRUCTIONS:

1. Put hex nut (item 4) on eyebolt (item 2) spinning nut to top end of threads.
2. Push washer (item 3) up to nut (item 4) and slide eyebolt thru anchor (item 1).
3. Put on last washer (item 3) and screw nylock nut (item5) till snug on anchor.
(Careful not to smash anchor with over tightening.)

