



411 West Congress St., Maple Lake, MN 55358 Toll Free 877-466-8837 www.wavearmor.net

Attaching Bumpers – Kit #21920 and 21921

Bumpers may be placed at any position on a dock section or Wave Port. Threaded inserts have been provided on the bumpers to attach to the decking, but it is not necessary to secure them with a bolt.

1. Slide a vertical bumper (Part G) or horizontal bumper (Part H) into the channel of a dock section. Line up a threaded insert on the bumper with a hole in the decking if you will be securing with a bolt.
2. Secure with a bolt and washer (Parts 2 & 3) if desired.



Vertical Bumper



Vertical Bumper installed on the Wave Dock



24" Horizontal Bumper



24" Horizontal Bumper installed on the Wave Dock.