



PRODUCT ASSEMBLY INSTRUCTIONS:



www.wavearmor.net

Item # | Product Name: #301278 & 301277 Heritage Dock Post Kit

Parts List:	Tools Needed:
1. 301232 PBeach or 301226 Tan Heritage Dock Post Qty 2	1. Mallet
2. Hdwe Bag	2. Lubricating spray (optional)
3.	3. 9/16" socket and ratchet
4.	4.
5.	5.

Assembly Instructions:

1. Position the dock post so it aligned with the channel in the dock. Use mallet to pound in the dock post until it is aligned with a slot in the dock at the desired position. Lubricate the channel as necessary. Secure with the 3/8 x 3 1/2" bolt and washer.

