



PRODUCT ASSEMBLY INSTRUCTIONS:

www.wavearmor.com

Item # | Product Name: 302472 Pro Extension Side Deck

Parts List:	Tools Needed:
1. Plastic Bottom Connector qty 2	1. Ratchet and 9/16" socket
2. Plastic Top Connector qty 2	2.
3. Side Deck	3.
4. 3/8 x 1 3/4" bolt qty 4, 3/8" lock washer qty 4, 3/8" heavy washer qty 4	4.
5.	5.
6.	6.
7.	7.

Assembly Instructions:

1. Move the side deck into position alongside the port as shown below.



2. Insert the bottom connectors and the top connectors into the post holes and secure with the 3/8 x 1 3/4" bolts, lock washers and heavy washers.

