



Item # | Product Name: 302511 Kayak Rack for the Kayak Launch

Parts List:	Tools Needed:
1. Plastic Kayak Rack qty 2	1. 9/16" socket and ratchet
2. 3/8 x 3 1/2" bolt qty 8, 3/8 lock washer qty 8, 3/8	2.
heavy washer qty 8	
3.	3.
4.	4.
5.	5.

Assembly Instructions:

1. Place kayak onto the launch, lining up the base holes with the threaded inserts in the kayak launch deck. Secure with the $3/8 \times 3 \frac{1}{2}$ " bolts, lock washers and heavy washers in four places shown below.





2. Repeat step 1 for the second rack in location shown below.

